

SEVERE SHOCK HAZARD! TURN POWER OFF AT INLINE SWITCH BEFORE CHANGING TUBE WIRING.

WIRE MULTI-TUBE RACK INTO THE SINGLE TUBE SET-UP. PLUG SINGLE TUBE INTO CART.